



ZN411

Front Cover Art





Table of Contents

Introduction	3
Setup	4
Battery Installation	4
Battery Saver	4
Code Saver	4
Power-On default	5
TV Punch Through	5
VCR Punch Through	5
Code Setup	5
Button Functions	6
Advanced DVD Button Functions	8
TV/VCR Punch-Through	9
TV/VCR and TV/DVD Combo units	9
Code Entry	10
Direct Code Entry	10
Code Search	11
Code Identification	12
Sleep Timer	13
Code List	13
Product Operation	18
Troubleshooting	19

Introduction

Congratulations on your purchase of a Zenith Universal Remote Control. Zenith Universal Remotes let you replace a broken or lost remote or combine more than one remote into one.

This remote control operates the common features of most but not all models and brands of IR Infrared Controlled Video Equipment. This remote may provide functions that are not available on your equipment. Some functions of your particular equipment (e.g. menu functions) may not be controlled by this remote. In such cases, use the original remote control for your equipment. Please use this manual to become familiar with your Zenith Universal Remote. After you are familiar with your remote the first thing you need to do is to install batteries and setup your remote for your particular product and brand.


Thank you for buying a Zenith remote and we hope it will give you many years of service.



Setup


Battery Installation

1. On the back of the remote, push down on the tab and lift the cover off.
2. Match the batteries to the + and - marks inside the battery case, then insert 2 AAA Alkaline batteries.
3. Press the battery cover back into place.



Battery Saver

Your remote automatically times out if the buttons are depressed more than 30 seconds. This will save your batteries should your remote get stuck in a place where the buttons remain depressed (e.g., between the sofa cushions).



Code Saver

You will have up to 10 minutes to change the batteries in your remote without losing codes you have programmed. However, do not press any buttons until batteries are installed in the remote. If buttons are pressed without batteries in the remote, all codes will be lost.

Power-On Default

The remote powers on in TV mode.

TV Volume/Mute Punch-Through

The TV Volume/Mute punch-through feature lets you control the Volume and Mute function of your TV in any mode programmed to be a VCR, Cable, or DVD device, without needing to change to TV mode.

VCR Punch-Through


Punch-through to VCR mode is only allowed in TV, and Cable modes.

Code Setup

The Code Search button is used to setup the remote. You can either setup the remote using the code for your brand of product, from the code tables, or you can search through the library of codes until you find a code that works for your product.


NOTE: You can store any kind of code under any mode (except TV). I.E. you can store a VCR code under the CBL key, or a DVD code under the VCR key, etc. However, you can only store TV codes under the TV key.

Code Search.



Button Functions

Some buttons on the remote might have functions that are referred to by different names on the device you are controlling. E.G. Prev. Ch. may be called RECALL, or ENTER may be called DISPLAY. These differences depend on the brand and model of your product. Also, this remote can only operate features that exist on your product. E.G., your product must be equipped with Prev. Ch. ability for the Prev. Ch. button to operate this feature.



TV, VCR, DVD, CBL Selects product to be operated.

Indicator light Lights when any button is pressed.

MUTE Turns off the TV sound while the picture remains. Use for **OK/Select** in Menu mode.

Code Search For setup.

POWER Turns product On or Off.


SLEEP Turns off the TV after a period of 1 to 99 minutes.

NUMBERS Enter numbers for direct channel selection. Some products require Enter to be pressed after channel selection.

ENTER Used after direct channel number entry to immediately change to the selected channel.

Note: The REC button must be pressed TWICE to record from your VCR. For some brands of VCRs, you might need to press the REC button once, then press it again for three seconds.

Button Functions, cont.



CHANNEL Up/Down Changes the channels.

VOLUME Up/Down Changes the volume level of the product, normally the TV.

QUIT exits from Menu mode.

MENU In/Out Toggles in and out of menu mode. Accesses the Menu functions of the device you are controlling.

Prev. Ch. Returns to the previously selected channel, or DVD repeat toggle.

Repeat performs DVD players "A-B Repeat" (or RPT A.B) function for repeat play of current Chapter or Track.

CC (Subtitle) TV Closed Caption (if your TV has this feature) or DVD Subtitle toggle.

TV/VCR/INPUT For some TVs, press repeatedly to select from available viewing sources (TV, CBL, etc.).

CHAPTER +/- controls DVD track selection i.e. DVD Track Skip Up/Down (in DVD mode). Note the DVD Transport keys also control DVD when in DVD Mode.

RECORD, PLAY, STOP, REW, FF, PAUSE VCR control buttons operate your VCR even when the remote is set to operate the TV. Also operates DVD Scan +/-.



Advanced Button Functions

DVD

Scan+ and Scan- buttons control the speed of Fast Forward and Reverse Playback respectively.

Chapter+ and **Chapter-** buttons respectively locate the succeeding or preceding Chapters or Tracks on a disc.

Repeat button performs DVD players "A-B Repeat" (or RPT A.B) function for repeat play of current Chapter or Track.

Play button is used to start Disc playback and for Menu selection on some DVD players.

Stop button stops Disc playback.

Pause button will pause Disc playback - press Play to resume.

Note - in DVD Mode the INPUT button activates the DVD Player's SETUP Menu.

MENU IN/OUT

The Menu In/Out button allows you to toggle in and out of Menu Mode. Pressing Menu In/Out brings up your device Menu. While in Menu mode the remote's red indicator light blinks continuously. The remote will exit Menu Mode after 20 seconds if no keys are pressed. While Menu Mode is active, the Menu, Channel, Volume, Mute and Mode keys perform the following functions:

MENU IN/OUT Exits/Enters Menu mode.

CHANNEL UP/DOWN Up/Down commands for on-screen Menu navigation.

VOLUME UP/DOWN Right/Left commands for on-screen Menu navigation.

MUTE OK/Select command for on-screen Menu selection.

TV Mode Key Quit, Exit or Clear command to quit on-screen Menu and return the remote to normal operation (red indicator is now off). Note this action is also available by pressing any Mode key.



TV/VCR Punch-Through

VCR Punch-through is only available in TV, and Cable modes, i.e. the 6 VCR keys (Play, Pause, Stop, Record, FF and Rewind) will punch-through to the device programmed under VCR when in TV mode.

The TV/VCR/INPUT button performs the TV/VCR antenna switch function when in VCR Mode.

The TV/VCR/INPUT button performs the A.B switch function when in Cable Mode.

The TV/VCR/INPUT button performs the INPUT source switch function when in TV Mode.

The TV/VCR/INPUT button performs the DVD Setup function when in DVD Mode.

Misc.

CC will activate the Closed Caption feature if your device has that feature.


TV/VCR and TV/DVD Combo units

Note that for some TV/VCR and TV/DVD combo units you might need to set up two different buttons to control both parts of the combo unit. E.G., (referring to the Direct Code Entry section on the following page) you might need to set up a code under the TV button to control the TV part of the combo unit AND a separate code for the VCR or DVD under any other button you choose.

Code Entry

Direct Code Entry

1. Press and hold the Code Search button until the red indicator stays on. Release the Code Search button.
2. Press and release the desired mode button (TV, VCR, etc.).
The red indicator blinks, then stays lit.
3. Enter the 3 digit code from the code tables. Note: after a valid code entry, the red indicator turns off. For an invalid code, the red indicator flashes.
4. With your device on, press CHANNEL Up. If the device responds, no further programming is required. Note: If some buttons do not operate your equipment, try one of the other codes for your brand.



Write your codes down here for easy reference later.

Type	Type stored	Code
TV	TV	
VCR		
DVD		
CBL		


10

Programming with Code Search

1. Manually turn on the device (TV, VCR, etc.) to be controlled.
2. Press and hold Code Search button until the red indicator stays on. Release the Code Search button.
3. Press and release the desired mode button (TV, VCR, etc.).
The red indicator blinks, then stays lit.
4. Press the Channel Up button repeatedly (up to 300 times) until the device to be controlled changes channel. The red indicator blinks, then stays lit. If you accidentally overshoot the code required, press the Channel Down button to backtrack through the library until the device changes channel. Pressing Channel Up changes direction to forward again. Press and release the Mute button to install the code.

The above assumes that you want to store VCR codes under the VCR button, DVD codes under DVD, etc. If you want to store a VCR code under DVD, etc., first follow the procedure on page 10 and try ANY DVD code from the code tables, e.g. press DVD in step 2, page 10, and then enter ANY VCR code. Then follow the steps above.

Note: If the device does not have a Channel Up button, use Play (VCR only) or Power instead. Code Search starts from the currently stored three digit number under that mode e.g. if the mode has 100 codes and the currently stored code is 050 then the Code Search starts from 051 continuing to 100 before looping back to 000 and finishing at 050. This simplifies the process if you find that several preprogrammed codes operate your device by allowing you to bypass codes already tried.




11

Code Identification

Code Identification

1. Press and hold Code Search button until the red indicator stays on. Release the Code Search button.
2. Press and release the desired mode button (TV, VCR, etc.).
The red indicator blinks, then stays lit.
3. Press and release the Code Search button. The indicator light blinks off.
4. To find the first digit for the code stored under the mode key pressed in step 2, press each numeric key from 0-9 in turn. When the indicator light blinks off the number you pressed is the first digit for the code you are searching for.
5. To find the second digit, repeat step 4, this time when the indicator light blinks off this is the second digit.
6. Repeat step 4 again to find the third digit.



Sleep Timer

The Sleep feature enables the remote to turn off the TV after a period of 1 to 99 minutes. Remote is to be in TV mode to set a Sleep Timer. This feature works even if your TV does not have this feature.

1. Press and release the TV Mode key.
2. Press and hold the Sleep button until LED remains on (occurring after approx. 2-3 seconds).
3. Release Sleep button.
4. Press and release the numeric keys (01-99) for the time required. The LED will blink off to indicate keypress acceptance and remain off after second keypress.
5. TV Sleep Timer now set.
6. **Leave the Remote pointing towards the TV with an unobstructed path.**

To cancel the Sleep Timer, press and hold the Sleep key until the LED blinks or press and release the Power key in TV Mode.

Code List

TV

ABEX	120
ADMIRAL	701 918
ADVENTURA	019
AIKO	407
AIWA	121 221
ALLERON	206
AMARK	603
AMTRON	906
AKAI	801
AMSTRAD	520
ANAM NATIONAL .	104 805
.....	901 906 920
AOC	002 003 102 119
.....	217 302 502 814
ARCHER	603
AUDIOVOX	906
BANG & OLUFSEN	620
BELCOR	002
BELL & HOWELL	506
.....	601 701
BRADFORD	906
BROKSONIC	215 316
BROKWOOD	002
CANDLE	002 019 402 502
CAPEHART	119
CELEBRITY	801
CENTURION	502
CETRONIC	805
CITIZEN	002 112 402 407
.....	502 512 701 805 906 319
CLAIRTONE	003

CLASSIC	805
CLP	018
CLP CLASSIC	007 006 002
COLORTYME ...	002 502 602
CONCERTO	002 502
CONCIERGE	713
CONTEC/CONY 003	802 805
.....	902 906
CRAIG	805 906
CROWN	805 906
CURTIS MATHES	002 103
.....	112 502 506
.....	512 601 701 704
CXC	805 906
DAEWOO	002 102 110
.....	214 303 311 314
.....	403 407 415 502 503
.....	611 614 805 809 909
DAYTRON	002 502
DIMENSIA	601 704
DUMONT	002 713
DYNASTY	805
ELEKTRA	701
ELECTROBAND	003 801
ELECTROHOME	002 502
.....	803 901 914
EMERSON .	002 003 004 005
.....	104 105 106 115 204
.....	205 206 213 304 305 316
.....	319 405 502 505 506 519
.....	604 605 705 804 805 903
.....	904 905 906
ENVISION	002 502



FISHER506 522
 606 619 902
 FUJITSU206 321
 FUNAI206 805 906
 FUTURETEC805 906
 GE002 006 007 018 107
 114 310 312 502 601
 704 719 803 806 810
 901 911
 GIBRALTER002 713
 GOLDSTAR 002 102 117 207
 217 307 502 818 914
 GRUNDY206 906
 HALLMARK002 502
 HARVARD906
 HITACHI002 016 116 216
 315 410 502 507 515
 519 607 615 622 701
 707 710 715 815 902 915
 IMA906
 INFINITY807
 INTEQ713
 JANEIL019
 JBL807
 JCB801
 JC PENNY002 007 102
 107 112 310 312
 402 502 512 601 704
 719 803 806 818 907
 JENSEN002 502
 JVC007 107 108
 308 510 607 902
 KAWASHO002 502 801
 KAYPANI119
 KEC805
 KENWOOD002 502 914
 KLOSS NOVABEAM019
 408 508
 KONKA203 208 219
 306 317 417
 KTV003 213 319
 608 703 805 906
 LODGENET601 701
 LOEWE722 807
 LOGIK601 701
 LUXMAN002 502
 LXI002 312 502 506
 512 601 704 719 807
 MAGNAVOX002 009 109
 118 209 309 402 408
 502 508 510 807 914 917
 MAJESTIC601 701
 MARANTZ002 502 807
 MEGATRON002 502 507
 MEI003
 MEMOREX002 115 206
 502 506 601 701 706
 MGA002 102 206
 502 619 803 914
 MIDLAND007 107 312
 713 719 818
 MINUTZ806
 MITSUBISHI002 102 206
 502 510 619
 709 803 814 914
 MONTGOMERY WARD 601
 701

MOTOROLA901 918
 MTC002 003 102
 112 502 512
 MULTITECH906
 MULTIVISION010
 NAD002 120 502 512
 NEC002 102 110 111
 502 510 602 901
 NIKEI805
 NIKKO002 407 502
 NTC407
 ONKING805
 ONWA805 906
 OPTIMUS120 618
 OPTONICA111 918
 ORION105 115 713
 PANASONIC007 107 416
 516 608 618 718 807 901
 PHILCO002 009 102 109
 309 402 408 502
 508 807 901 914
 PHILIPS002 009 020 109
 122 202 209 210 222
 310 322 402 408 422
 508 510 807 822 901
 914 917 919 922
 PHILIPS/MAGNAVOX ... 020
 422 919 922
 PILOT002
 PIONEER002 120
 502 519 610
 PORTLAND002 102
 407 502
 PRECISION218
 PRICE CLUB112
 PRISM107
 PROSCAN ..312 601 704 719
 PROTON002 119 220
 502 820 910
 PULSAR713
 PULSER002
 QUASAR ...007 107 416 516
 608 618 718 807 901
 RADIO SHACK/REALISTIC .
 002 021 111 117 406
 502 506 601 618 704
 705 805 818 906 914
 RCA002 021 011 102 211
 302 312 318 320 406
 409 411 420 502 511 514
 519 601702 711 719 809
 811 901 909 911 912 914
 RHAPSODY003
 RUNCO713
 SAMPO002 119 502 818
 SAMSUNG ..002 012 102 103
 112 212 502 512 818 914
 SAMSUX502
 SANSUI115 215
 SANYO002 412 506
 522 612 619 902
 SCOTCH002 502
 SCOTT002 004 105
 206 502 805 906
 SEARS002 112 206 312
 502 506 512 520 601
 612 619 704 719 902 914

SHARP 002 013 014 111 502
 509 712 812 813 913 918
 SHOGUN002
 SIGNATURE601 701 903
 SIMPSON402
 SONIC003
 SONY202 414 708 801
 SOUNDESIGN ..002 206 402
 502 805 906
 SPECTRAVISION921
 SQUAREVIEW520
 SSS002 805 906
 STARLITE906
 SUPREMACY019
 SUPREME801
 SYLVANIA002 009 109
 209 309 402 408 502
 508 717 807 914 917
 SYMPHONIC520 904 906
 TANDY918
 TATUNG901
 TECHNICS007 107
 TECHWOOD002 007
 107 502
 TEKNIKA ..002 019 102 112
 206 209 402 407 502 512
 601 618 701 805 902 906
 TELECAPTION313
 TELERENT601 701
 TERA002 220
 TMK002 502
 TOSHIBA ...112 313 413 419
 506 510 512 517 613 902
 UNIVERSAL310 806
 VICTOR607
 VIDTECH002 102 502
 VIKING019
 WARDS002 004 009 102
 109 111 206 209 310
 408 502 508 513 601
 701 704 806 807 914
 WHITE WESTINGHOUSE ...
 311 611
 YAMAHA ...002 102 502 914
 ZENITH002 008 115 215
 405 407 507 601
 701 713 903 916

MAGNAVOX441 442
 MARANTZ441 442
 MITSUBISHI841
 MUSTEK744
 NAD944
 NAKAMICHI844
 ONKYO843
 OPTIMUS042 545
 ORITRON143
 PANASONIC641 741
 PHILIPS441 442 943
 PIONEER042 545
 PROSCAN941
 RADIOSHACK835 945
 RCA644 835 941 945
 SAMSUNG342
 SAMPO343
 SEG444
 SHARP341
 SHERWOOD144
 SHINCO644
 SONY541
 TEAC042 545
 THETA DIGITAL042 545
 TOSHIBA441 245
 WHARFEDALE845
 YAMAHA641 643
 YAMAKAWA445
 ZENITH241 142 345

Laser Disc

DENON132
 PIONEER132
 PROSCAN432
 RCA432
 SANYO824
 SONY933
 ZENITH824

Cable

ABC048 148 248
 348 747 847 947
 ALLEGRO054 154
 AMERICAST354
 ANTRONIX448 548
 ARCHER448 548 648 748
 CABLETENNA448
 CABLEVIEW448
 CENTURY748
 CITIZEN748
 COLOUR VOICE848 948
 COMTRONICS049 149
 CONTEC/CONY249
 EASTERN349
 GARRARD748
 GC ELECTRONICS548
 GEMINI449 549
 GE556
 GENERAL INSTRUMENT ...
 053 453 454 552 554
 654 752 754 947 952
 HAMLIN649 749 849
 HITACHI947

DVD

AIWA043
 AKAI141
 APEX044
 DAEWOO645 745
 DENON641 743
 ELTA045 145
 EMERSON241
 FISHER243
 GE644
 GO-VIDEO342 244
 HITACHI042 543 545
 HARMAN/KARDON344
 JVC242 443
 INTEGRA843
 KENWOOD641 544
 KONKA642 742 842 942





HYTEX 847
 JASCO 748
 JERROLD 048 050 148
 254 348 449 454 552
 554 652 747 752 947
 MAGNAVOX 150
 MEMOREX 250
 MOVIE TIME 350 847
 NSC 350 847
 OAK 249 550 847
 PACE 854
 PANASONIC 452 647
 PARAGON 250
 PHILIPS 150 549 650 748
 750 848 850 948
 PIONEER 051 451 950
 PULSAR 250
 RADIO SHACK .055 152 154
 RCA 352 647
 REALISTIC 548
 REGAL 849
 REGENCY 349
 REMBRANDT 947
 RUNCO 250
 SAMSUNG 049 051
 SCIENTIFIC ATLANTA 248
 251 351 451
 SIGNAL 049 449
 SIGNATURE 947
 SL MARX 049
 SPRUCER 647
 STANDARD COMPONENTS
 551
 STARCOM 348 449 747
 STARGATE 049 449
 STAR SIGHT 653
 STAR SIGHT CABLE
 SERVICE 352
 STARQUEST 449
 STAR TRAK 253
 TANDY 651
 TELEVIEW 049
 TELEWEST 854
 TEXSCAN 551
 TOCOM 048 751 952
 TOSHIBA 250
 TUSA 449
 TV86 350
 UNIKA 448 548 748
 UNITED ARTISTS 847
 UNITED CABLE 747
 UNIVERSAL 448 548
 648 748 851
 VIDEOWAY 052
 VIEWSTAR 149 150 350 651
 VIDEO TECH 656
 ZENITH 054 154 250
 353 354 450 553 653
 753 853 951 953 954

VCR

ADMIRAL 224
 ADVENTURA 726
 AIKO 826
 AIWA 126 324 528 726

AKAI 027 235 335 424
 524 624 724 924
 ALLEGRO 326 534 925
 AMERICAN HIGH ... 130 226
 ASHA 425
 AUDIO DYNAMICS .025 436
 AUDIOVOX 525
 DAEWOO 529
 BELL & HOWELL 428
 BEAUMARK 425
 BROKSONIC 227 325
 530 626 632
 CALIX 525
 CANDLE 025 026 425
 525 625 725 825
 CANNON ... 130 226 535 635
 CAPEHART 135 534
 CARVER 330
 CCE 230 826
 CITIZEN ... 025 026 425 525
 625 725 825 826
 COLORTYME 025
 COLT 230
 CRAIG 230 425 426 525
 CURTIS MATHES 025
 124 130 226 324
 425 526 635 725
 CYBERNEX 425
 DAEWOO ..026 135 625 626
 726 825 826 926
 DAYTRON 135
 DBX 025 436
 DIMENSIA 124
 DYNATECH 324 726
 ELECTROHOME027 525
 ELECTROPHONIC 525
 EMERSON 027 028 127
 128 130 226 227 228 324
 325 327 427 428 525 526
 527 528 625 626 627 628
 630 634 724 726 727 735
 827 828 927
 FISHER 025 029 129 328
 330 426 428 928
 FUJI 130 226 524
 FUNAI 324 726 924
 GARRARD 7 26
 GE 124 130 136 226
 425 429 635 835
 GOLDSTAR 025 236 525
 GRADIENTE 726
 GO-VIDEO 139 438 537
 HARLEY DAVIDSON 726
 HARMAN KARDON 025 930
 HARWOOD 230
 HEADQUARTER 428
 HITACHI ... 136 235 324 336
 538 629 638 829 834
 HI-Q 426
 INSTANT REPLAY 130
 226 924
 INTEQ 525
 JCL 130 226
 JC PENNEY 025 130 235
 425 428 436 525
 629 635 834 935
 JENSEN 235 629

JVC 025 235 239
 326 339 428 436
 KENWOOD 025 235
 428 436 725
 KLH 230 237
 KODAK 130 226 525
 LLOYD 324 726
 LOGIK 230
 LXI 525
 MAGNAVOX . 130 226 330 5
 34 536 635 734
 MAGNIN 425
 MARANTZ 025 130 226 330
 428 436 530 535 725
 MARTA 525
 MATSUSHITA 130 226
 MEI 130 226
 MEMOREX 130 224 226
 324 335 425 426
 428 525 534 726
 MGA 027 630
 MGN TECHNOLOGY 425
 MIDLAND 429
 MINOLTA 629 834
 MITSUBISHI 027 031 131
 229 231 329 431 436
 531 629 630 730 930
 MONTGOMERY WARD 224
 631
 MOTOROLA 130 224 226
 MTC 324 425 726
 MULTITECH 324 425
 726 429 230
 NEC 025 235 428 526 530
 725 731 831 931 436
 NIKKO 525
 NOBLEX 425
 OLYMPUS 130 226
 OPTIMUS 035 224 525
 537 737 837 937
 OPTONICA 537 631
 ORION 227
 PANASONIC 035 039 130
 226 635 636 937 938
 PENTAX ... 136 629 725 834
 PENTEX RESEARCH 025
 PHILCO 130 226 330 635
 PHILIPS 130 226 330 430
 434 439 536 631
 734 738 934 937
 PHILIPS/MAGNAVOX ... 434
 934
 PILOT 5 25
 PIONEER ... 132 232 436 629
 PORTLAND026 135 725 825
 PROSCAN 124
 PROTEC 230
 PULSAR 534
 QUARTER 428
 QUARTZ 428
 QUASAR 039 130
 635 636 937
 RCA 033 124 130 133 136
 226 233 332 424 425
 432 532 629 636 732
 832 834 835 837 932


RADIOSHACK ..027 029 035
 124 129 130 224 226 324
 335 425 426 428 525 631
 635 726 737 835 837 937
 RADIX 525
 RANDEX 525
 REALISTIC 027 029 035
 124 129 130 224 226 324
 335 425 426 428 525 631
 635 726 737 837 937
 REPLAY 938
 RICOH 936
 RUNCO 534
 SAMSUNG ..037 335 425 427
 429 537 624 625 629
 SANKY 224 534
 SANSUI 235 333 436
 SANYO 328 425 426 428
 SCOTT 325 327 433 625
 626 630 735 927
 SEARS 029 129 130 226
 330 426 428 525
 629 834 928 935
 SHARP 027 224 324 338
 631 637 737 825
 SHINTOM 230 337
 524 629 936
 SHOGUN 425
 SIGNATURE 324
 SINGER 130 226 230
 SONY 034 038 138
 238 524 838 936
 STS 130 226 629 834
 SYLVANIA 130 324 330
 536 630 635 726
 SYMPHONIC 225 324 726
 TANDY 324 428
 TASHIKO 525
 TATUNG 235
 TEAC 235 324 726
 TECHNICS 035 130 226
 TEKNIKA 130 134 226
 324 525 726
 TiVo 738 838
 TOSHIBA 029 330 433
 625 629 630 735
 TOTEVISION 425 525
 TMK 425 526 828
 UNITECH 425
 VECTOR RESEARCH 025
 436 625 725
 VICTOR 436
 VIDEO CONCEPTS ..025 027
 436 625 725
 VIDEOSONIC 425
 WARDS 027 130 224 226
 230 234 324 425 426 525
 625 629 631 726 735 834
 WHITE WESTINGHOUSE ...
 324 924
 XR-1000 130 226 230 726
 YAMAHA ... 025 235 428 436
 ZENITH 030 036 125 326
 436 437 524 525 534 632
 638 729 824 925 929 936

Product Operation

After the batteries are installed and you have programmed the remote for the codes that operate your products, you can use your remote to operate a TV, VCR, Cable Box, etc.




TV (Press **TV** First)



VCR
(Press **VCR** First)



DVD Player
(Press **DVD** first)




Cable Box
(Press **CBL** first)



To Operate:

1. Press the TV, VCR, DVD, CBL, etc. button (depending on which product you want to operate).
2. Aim the remote at the product.
3. Press POWER to turn on the product.
4. Press other buttons to operate the features of your product.



Troubleshooting

Remote does not operate your product.

- Press the mode button of the product you want to control.
- Program the remote with a new code.
- Install new batteries. (You might have to reprogram your remote after installing new batteries.)
- Remote may not be compatible with your product.

Remote does not operate some features of your product.

- Program remote with a new code.
- Remote may not be able to operate all features of your product or button names might be different than your product.

Indicator light blinks after you program a product code.

- Remote did not accept the code.
- Try to program the code again or try a different code.



90 Day Warranty

This product is manufactured to ZENITH specifications and is free from defects in material, workmanship and assembly. This warranty extends only to the original purchaser and is nontransferable. Should a defect occur under normal operating conditions within 90 days from the date of purchase, ZENITH will provide a comparable replacement free of charge within the warranty period, to the original purchaser. Defective product must be returned, with the dated proof of purchase, to the place of purchase for replacement. This warranty does not extend to the product if it has been damaged or rendered defective as a result of accident, misuse, abuse, tampering with or modification. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ZENITH BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER IN CONTRACT, TORT OR NEGLIGENCE. Some States do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some States do not allow exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific rights and you may also have other rights, which vary from State to State.

Made in China-TC, Quality Assured in USA
Clifton, NJ 07014-1115

ZN411
Back
Cover Art

