

## SC-300 SERIES CODE LIST

### TV CODES (SC-310, SC-320, SC-330, SC-331, SC-340)

A Mark 450	Hitachi 468 459 450 443 441	Proton 454 450 437 428 422
Action 410	440 437 436 428 423	408 406
Admiral 460 443 442 437 434 432	422 419 478	Pulsar 459 453 428 408
Advent 448	Infinity 428	Quasar 463 441 437 411
Alai 440 438 408	Inteq, Also see Zenith 432	Radio Shack, Also see Optimus/ Realistic 450 445 440
Anam 422	JBL 420	437 434 427 422 413
Anam National 411	JC Penney 473 482 481 451 450	411 410 408
AOC 482 459 453 450 428	441 437 422 408 406	RCA, Also see Proscan 473 482
408 406	Jensen, Also see NEC 408	481 459 457 450 437 428
Audiovox 410	JVC 473 444 441	422 411
Baycraft 442 436 428	Kawasho 438 406	Rent-Co 446
Bell & Howell 460 443 434 432	Kenwood 428 408 406	Ronco 440
Bratsonic 454 434 422 408 402	Kloss Novabeam 411	Sampo 441 428 411 406
Candle, Also see Citizen 473 459 455	KMC 450	Samsung 473 450 443 434 428
454 450 444 434 428 422	KTV 464 450 428 422 410 406	408 406
408 406	Lloyds 453 440 428	Sanyo, Also see Fisher / LXI / Sears
408 406	Logik 461 460	451 431 427 414
Citizn, Also see Citizen 454 444	LXI, Also see Fisher / Sanyo / Sears	450 442 428 422 410
Classic 438 408	481 474 437 434 408	Sears, Also see Fisher / LXI / Sanyo
Colorform 473 449 446 437 434	Magnasonic, Also see Daewoo/Funai/ Goldstar/Nikko	481 451 450 448 437
428 408	459 443 408	436 434 431 430 427
Conchario 434	Magnavox 455 446 444 443 441	422 414 408
Conlee Comy 422 410	434 428 408 406	Sharp 455 455 450 446 445 443
Craig 473 454 422 410	Marantz 434 428 408 406	440 438 431 428 422 413
Cresley 434	Machushita, Also see Panasonic 447	Signature 2080 460 445 427
Crown 450	Megatron, Also see Hitachi 436	Silver 408
Curtis 456 446 408	Memorex 460 440 427 408	Simpson 408
Curtis Mathes 473 460 450 437 434	MGA, Also see Mitsubishi 440 408	Sony 465 450 438 404
428 408 406	Mitsubishi, Also see MGA 452 450	Soundesige 428 422 408
CXC 422 410	447 440 441 428 423 408	SSS 422 408 406
Daewoo, Also see Funai/Goldstar/ Magnasonic/Nikko 467 463	406 405	Sylvania 459 455 446 444 434 430
459 456 450 446 444 428	Montgomery Ward 473 460 446	428 408 406
411 408 406	444 443 437 434 432	Symphonic 474 410 409
Daytron 459 456 450 428	428 422 413 408 406	Tandy 434
Denon 468	MTC 473 459 434 428 427	Tatung 454 424 411
Electrohome 450 440 428 408	408 406	Technics, Also see Panasonic
Emerson 473 469 450 443 442 428	Multivision 464	441 435
425 422 410 409 408	NAD 408	Techwood 434 408
Envision 408 406	NEC 449 428 408 406	Teknika 466 460 459 453 450 428
Fisher, Also see LXI / Sanyo / Sears	Nikko, Also see Daewoo/Funai/ Goldstar/Magnasonic 459	422 410 406
451 448 438 431 427	473	Teletunkon 428
Fortress 408	Nishl 473	TMK 428 408
Funai, Also see Daewoo/Goldstar/ Magnasonic/Nikko	Nyon 481 408	Toshiba 473 452 451 448 444 427
474 422 410 409	Onwa 422	408 405
Futuretech 422	Optimus, Also see Radio Shack/ Realistic 458	Television 437
Garrard 474	469 442	Ultra 459
GE 473 482 481 457 450 441	Panasonic, Also see Matsushita 474	Uniden 438
437 428 422 412 411 408	463 462 459 441 437 422	Video Concepts 447 422
Go Video 473	411 410	Viditron 434
Goldstar, Also see Daewoo/Funai/ Magnasonic/Nikko 453	Philips 444 434 428	Vidtech 406
432 450 437 428 408 406	Pioneer 458 428 411	White Westinghouse, Also see Emerson/Symphonic 409
Hallmark 408	Portland 456 450 428 408 406	XR 1000 474 460
Harley Davidson, Also see RCA 437	Prima 461	Yamaha 459 428 406
Harman Kardon 408	Proscan, Also see RCA 437	Zenith 474 460 459 438 432

### VCR CODES (SC-320, SC-330, SC-331, SC-340)

Action 677	Dynatech 668 614	JVC 661 648 644 603 641
Admiral 631	Electrohome 683 613 608 606	636 630
Alwa 628 602	Emerson 694 693 692 691 685 683	Kenwood 673 654 644 603 607
Alai 643 703 624 616 611	674 669 664 661 659 656	Lloyds 681 673 657 628
Beaumont 610	618 647 628 622 617 614	Logik 662 632
Broksonic 692 691 685 674 659	613 608 606	LXI, Also see Sears/Sanyo/Fisher 628
647 606	Fisher, Also see LXI/Sanyo/Sears	Magnasonic, Also see Daewoo/Funai/ Goldstar/Nikko 677
Candle, Also see Citizen 677 664 657	681 668 654 651 615 614	632 608
628 626 623 622 614 610	Funai, Also see Daewoo/Goldstar/ Magnasonic/Nikko 657	Magnavox 661 656 648 636 634
608 607 606	620 625	632 628 626 614 606
Canon 626	Garrard 628	Magna, Also see MGN 610
Capcharl 623	GE 672 664 648 626 618 610	Magnin 673 607 606
Citizen, Also see Candle 664 657 628	628	Marla 608
626 614	Genazza 628	Matsui 628
Colorform 664 663 626	Go Video 695 686 633 632 619	Matsushita, Also see Panasonic 626
Craig 689 681 632 608	618 610	MEI 668
Criterion 632	Goldstar, Also see Daewoo/Funai/ Magnasonic/Nikko 695 642	Memorex 681 642 631 630 621
Curtis Mathes 673 664 645 628 626	610 608 607	608 601
622 614 610 607	Hitachi 683 672 668 664 630 628	MGA, Also see Mitsubishi 613
Daewoo, Also see Funai/Goldstar/ Magnasonic/Nikko 677 675	608	MGN, Also see Magnin 610
623 622 614	Homeline 608	Midland 657
Daytron 677 623	JC Penney 655 632 630 626	Minolta 630
Denon 630 613	610 608	
	Jensen 646 644 603	

### VCR CODES CONTINUED (SC-320, SC-330, SC-331, SC-340)

Mitsubishi, Also see MGA 683 681	670 635 613 608	Quasar, Also see Technics 696 664	Symphonic 681 673 657 644 603
670 635 613 608	670 635 613 608	626 608	620 625 604
Montgomery Ward 683 681 631 628	614 610 608 606 604	Radio Shack, Also see Optimus/ Realistic 625 608	Tatung 661 644 603
632 628	632 628	630 626 613 610 609	Teac 628
MTC 642 628 608 607	673 668 661 645 644 603	Realistic, Also see Optimus/ Radio Shack 683 681 651	Technics, Also see Panasonic
NEC 673 668 661 645 644 603	642 628 608 607	631 628 626 610 608 604	696 687 626
673 668 661 645 644 603	673 668 661 645 644 603	694 693 692 685 683 674	Teknika 660 628 626 608
642 628 608 607	669 661 659 658 648 628	695 664 658 657 628 610	Thomas 628
Optimus, Also see Radio Shack/ Realistic 695 631 609 608	617 614 613 608 606	Sansul 674 661 632	TMK 622
694 693 692 685 683 674	Panasonic, Also see Matsushita	Sanyo, Also see Fisher/Sears	Toshiba 684 650 681 677 666 637
669 661 659 658 648 628	702 696 681 680 664 658	681 654 651 615	Television 626 608
617 614 613 608 606	656 632 626 614 613 608	659 656 647 617 614 608	Ultra 623
Panasonic, Also see Matsushita	673 630	Sears, Also see Fisher/Sanyo 681 676	Unitac 658 657
702 696 681 680 664 658	Philips 634 626 614 606	673 661 654 651 630 628	Vector Research 673
656 632 626 614 613 608	Pioneer 679 634 609	626 615 614 608	Video Concepts 673
Pentax 673 630	Portland 623	683 660 645 631 604	White Westinghouse, Also see Emerson/Symphonic 628
Philips 634 626 614 606	Pro Max 695	Sharp 683 660 645 631 604	XR 1000 632 628
Pioneer 679 634 609	Proscan, Also see RCA 680 678 664	Shitem 632	Yamaha 673 644 603 613
Portland 623	632	Singer 2000 632	Zenith 664 703 642 641 628 624
Pro Max 695	Pulsar 695 677 657 652 628	Sony 683 681 668 666 652 644	611 608
Proscan, Also see RCA 680 678 664	626 610	603 629 620 616	
Pulsar 695 677 657 652 628		Sylvania 656 634 628 626 606	
626 610			

### CABLE CODES (SC-330, SC-331, SC-340)

ABC 231 229 224 221 218 217	JVC 203	Samsung 217 215
210 206 204	Magnavox 229	Scientific Atlanta 251 247 241 231
Archer 235 230 221	Memorex 245 224 221 218 212	213 207
Delcor 235	Micro Com 248	Sears 228
DBX 228	Millenium3 252	Signal 215
Cableview 227	Monarch 215	Signature 2000 229
Century 252	Montgomery Ward 229	Sprucer 222 207
Century 254 221	Movie Time 221 220 215 206	Starcom 245 243 233 241 229
Chizen 230 221 215	Northcoast 222	219 210
Contec 231 226 224 216 213 208	Novavision 251	Stargate 241 215
207 205 201	NSC 221 220 206 205 200	Sylvania 239 228
Diamond 226	Oak 226 224 205	Telecaption 240
Eagle 218	Panasonic 223 212 207 201	Television 215
Eastern 202	Paragon 221 218 212	Texscan 239 236
GC Electronics 234 230 221 215 211	Philips 244 233 232 221 218	Tecom 256 220 207 206 205 204
Gemini 246 227 225	Pioneer 223 217	Uniba 221
General Instruments 229 216	Prelude 253	Universal 243 242 235 234 230 221
214 249	Pulsar 230 215	U.S. Electronics 231 229 210
Hamlin 226 209	Radio Shack 235 230 221	Viewstar 238 237 232 218
Hitachi 229 228	Recoton 226	Warner 217
Jasco 230	Regal 226	Zenith 222 212
Jerrold 229 218 216 214 200 203	Rombrant 205	

### CD CODES (SC-340)

Acurus 833	Lloyds 853	Radio Shack, Also see Optimus/ Realistic 920 902 893
Adcom 862	Luzman 925 881 873 872 871	886 884
ADS 909 860	870 863	RCA 910 882 823
Alwa 804 914 909 889 874	Magnavox 928 897 882 828	Realistic, Also see Optimus/ Radio Shack 921 904 893
864 841	Marantz 897 861 828 819	834 831 821
Alai 931 876 855 818	McIntosh 812	924 897 834 828 808
Arcom 897	Moridian 897	Samsung 899 857
Audio Research 897	Mission 897	Sansul 916 868 863 851
BSR 845 825	Mitsubishi 855	Sanyo 921
California Audio Labs 883 833	NAD 922 858 826	Scott 900 882
Carver 932 921 911 906 828	Naim 897	Sears, Also see LXI 885
Craig 888	Nakamichi 915 898 875	Sharp 927 891
Crown 879	NEC 862	Sherwood 920 902 886 884 838
Curtis Mathes 883	NSM 856	824 802
DBX 820	Onkyo 899 839 837 836 817	Shure 844
Denon 938 928 894	809 800	Sony 852 815 941 930 926
Emerson 917 904	Optimus, Also see Radio Shack/ Realistic 940 927 893 882	918 889 854 848 816
Enlightened Audio 864	867 859 830 822 804	807 801 936
Fisher 921 910 849 848	Ovation 810	Symphonic 882
Garrard 827	Panasonic, Also see Technics	Teac 940 920 909 905 896 878
Harman Kardon 846 859 855	891 883 869 807	865 842 834 826 808
Hitachi 892 847 835	Parasound 834	Technics, Also see Panasonic 807
JVC 923 913 903 829 813	Philips 897 895	891 883 878
Kenwood 806 899 886 866 805	Pioneer 907 891 867 865 864 854	Toshiba 887 880
Koss 890 800	Proced 843 840	Yamaha 929 924 919 908 811 803
Krell 897	Proscan 910	
Kyocera 877	Quasar 883	
Librarian 814		